


Exploded view Flex 3/4 and UltraFlex 3/4



Spare parts Flex 3

7925160090

Art. no.	Description
0050101040	Hose set (Ultra)Flex
0507270010	Manual Euromate (Ultra)Flex
0703030250	Spring for collar rotating hinge (Ultra)Flex
0801820090	Collar rotating hinge
0801850090	Arm section (Ultra)Flex 3
0805090010	Tube holder (Ultra)Flex
0805090030	Throat (Ultra)Flex (p/pc; set = 2 pcs)
0840101030	Bush Ø 203 mm
9820060030	Spring replacement set (Ultra)Flex 3 wall/unit side
9823000000	Euromate RotaHood, complete
9824000010	Hinge set RotaHood
9824000040	Friction clamp Flex complete
9824000050	Rotating flange (Ultra)Flex

Spare parts Flex 4

7925210090

Art. no.	Description
0050101040	Hose set (Ultra)Flex
0507270010	Manual Euromate (Ultra)Flex
0703030250	Spring for collar rotating hinge (Ultra)Flex
0801800090	Arm section (Ultra)Flex 4/NEC
0801820090	Collar rotating hinge
0805090010	Tube holder (Ultra)Flex
0805090030	Throat (Ultra)Flex (p/pc; set = 2 pcs)
0840101030	Bush Ø 203 mm
9820060050	Spring replacement set (Ultra)Flex 4 wall/unit side
9823000000	Euromate RotaHood, complete
9824000010	Hinge set RotaHood
9824000040	Friction clamp Flex complete
9824000050	Rotating flange (Ultra)Flex