


Exploded view Flex 3/4 and UltraFlex 3/4



Spare parts **UltraFlex 3**

7925170090

Art. no.	Description
0050101040	Hose set (Ultra)Flex
0507270010	Manual Euromate (Ultra)Flex
0703030250	Spring for collar rotating hinge (Ultra)Flex
0703030280	Distance spring hose middle UltraFlex
0801820090	Collar rotating hinge
0801850090	Arm section (Ultra)Flex 3
0805090010	Tube holder (Ultra)Flex
0805090030	Throat (Ultra)Flex (p/pc; set = 2 pcs)
0840101030	Bush Ø 203 mm
9820060020	Spring replacement set UltraFlex 3 hood side
9820060030	Spring replacement set (Ultra)Flex 3 wall/unit side
9823000000	Euromate RotaHood, complete
9824000010	Hinge set RotaHood
9824000050	Rotating flange (Ultra)Flex

Spare parts **UltraFlex 4**

7925220090

Art. no.	Description
0050101040	Hose set (Ultra)Flex
0507270010	Manual Euromate (Ultra)Flex
0703030250	Spring for collar rotating hinge (Ultra)Flex
0703030280	Distance spring hose middle UltraFlex
0801800090	Arm section (Ultra)Flex 4/NEC
0801820090	Collar rotating hinge
0805090010	Tube holder (Ultra)Flex
0805090030	Throat (Ultra)Flex (p/pc; set = 2 pcs)
0840101030	Bush Ø 203 mm
9820060040	Spring replacement set UltraFlex 4 hood side
9820060050	Spring replacement set (Ultra)Flex 4 wall/unit side
9823000000	Euromate RotaHood, complete
9824000010	Hinge set RotaHood
9824000050	Rotating flange (Ultra)Flex